





















## Changing the Sound (Strumming Pad)



Hold down the  button and press the string that correspond to the desired sound icons to change the sound of Strumming Pad.




>>Guitars



>>Basses

## Drum Pads



The **BAND** features 7 Drum Pads with velocity sensitivity and RGB backlighting. The sound from Pads 1 to 7 are Bass Drum, Acoustic Snare, Closed Hi-Hat, Open Hi-Hat, Low-Mid Tom, High Tom, and Crash Cymbal.


# Connecting Bluetooth MIDI

Let's use "GarageBand" for iOS as an example.


Step 1. Enable Bluetooth in your smartphone's settings.




Step 2: Launch GarageBand and choose an instrument. Next, click on the gear icon located in the upper-right corner.




Step 3: Tap on the "Song Settings".



Step 4: Tap on the "Advanced".



Step 5: Tap on the "Bluetooth MIDI Devices".



Step 6: Find and select "BAND" in the list of devices. If "Connected" is displayed, the connection has been successful.

