



# X mini Upgrade Instructions

## 一 . Materials required

1. 1X USB cable
2. 1X X mini
3. 1X windows system computer( only support windwos XP, windows7, windows8, windows8.1, windwos 10 version)
4. Download the latest firmware upgrade package from the official website.


## 二 . Upgrade process


1. Use USB cable to connect computer with X mini.
2. Unzip the X mini firmware upgrade package you downloaded, double click  update.exe . See picture 1 the computer window shows:



Picture 1

1. Unplug the USB cable, disconnect computer with X mini.
2. Use USB cable to connect computer and X mini again.

1. Double click  update.exe again. Tbox 2x2 completed upgraded automatically, see picture 2. (Target update successfully! shows upgrade successfully, click any button to close the window.)



```
G:\1.产品程序\Tbox2X2\Firmware\48M_C6T6_Tbox2X2_FW_V1.0.0.2_170511A.zip\48M_C6T6...
Update U0.3 - Update MIDIPLUS Tbox 2X2 System
OK: File 'Tbox2X2.led' is open.
The Update Device is Open successfully:
MIDIIN Device: Tbox Upgrade
MIDIOUT Device: Tbox Upgrade
Transferring.. 100% done.
Target update successfully!

The System is restarted, please wait!

请按任意键继续. . .
```

Remark: There is small chance that upgrade failed, you can repeat the upgrade process if this happens.

/\*\*\*\*\*End\*\*\*\*\*/